

The counter function can be added easily by connecting this to the existing HIOS power supply.


**(P)** 

**(P)** 





## Configuration of components




### Connectable power supplies and screwdrivers

Power supplies	Connectable screwdrivers (OPC)
T-30BL (for one screwdriver)	BLG-4000-OPC, BL-2000-OPC, BL-3000-OPC
T-70BL (for one screwdriver)	BLG-4000-OPC, BLG-5000-OPC, BL-2000-OPC, BL-3000-OPC, BL-5000-OPC, BL-5020-OPC, BL-7000-OPC

## For CL, SS and $\alpha$ Series




## Configuration of components



#### Connectable power supplies and screwdrivers

Power supplies		Connectable screwdrivers
CLT-30 (for one screwdriver)		CL-2000, CL-3000, SS-2000, SS-3000
CLT-60 (for one screwdriver)		CL-2000, CL-3000, CL-4000, CL-6000, CL-6500, CL-7000
CLT-100 (for two screwdrivers)		SS-2000, SS-3000, SS-4000, SS-6500, SS-7000, α-4500, α-5000, α-6500*
MC-70L	Up to 20 screwdrivers	CL-2000, CL-3000CL-4000, SS-2000SS-3000, SS-4000
+CB-1055	Up to 10 screwdrivers	CL-6000, CL-6500, CL-7000, SS-6500, SS-7000, α-4500, α-5000
(multiple)	Up to 5 screwdrivers	κ-6500
CLT-80 (for one screwdriver)		CL-9000

<sup>\*</sup>  $\alpha$ -6500 cannot be connected with CLT-100 (for two screwdrivers).





Only 120g!

This palm-sized compact counter can be directly connected to a screwdriver.


1

(P)





## Connection of components



### Connectable power supplies and screwdrivers

Power supplies	Screwdrivers (OPC)
T-30BL (for one screwdriver)	BLG-4000-OPC, BL-2000-OPC, BL-3000-OPC
T-70BL (for one screwdriver)	BLG-4000-OPC, BLG-5000-OPC, BL-2000-OPC, BL-3000-OPC, BL-5000-OPC, BL-5020-OPC, BL-7000-OPC

- · Always use BLOP-SC3 by hanging it from the balancer.
- ·Do not use this device for horizontal screw tightening.

# Components and Functions of Compact Separate Counter SC3

